

SUPER DON QUIXOTE TM



**A Demon Attacks Don Quix-ote, Who Is
Moving Towards The Castle To Rescue His Love Isabella**

UNIVERSAL.

© 1984 UNIVERSAL CO., LTD.

UNIVERSAL

SUPER DON QUIXOTE



HOW TO PLAY

- Don Quix-ote is operated by the working the lever and button.
- The lever determines the direction in which Don Quix-ote moves and its timing. When an arrow mark appears on the screen, depress the lever towards it.
- The button pressed at the right time causes Don Quix-ote to jump, pull out the sword, or throw something, etc.

SPECIFICATIONS

1800m/m(H)
640m/m(W)
800m/m(D)

AC100V,115V,220V
50/60Hz
180W(20")

¥96-2835



Universal Sales Co., Ltd.
1-2-1, Nishi-Shinjuku, Shinjuku-ku, Tokyo 160, Japan
Phone: 03-451-4504, 4505 Cable: URMANSFACT
Telex: J21348 JUMCOJ

Universal U.S.A., Inc.
2250 York Street, Suite 200, Culver City 90230, U.S.A.
Phone: 408-721-4851, 5- Telex: 112247 ULSB USA 0014
Mail: Lot of 200 lots - Developing, manufacture, sale, and
imports & exports of amusement machines

European Office
81 Tottenham Court Road, London W1A 1EY
Phone: 01-431-1713 Telex: 88265 ELCCOM

Printed in Japan '84 9/12 3,000